



Dear user of Walkstool,

Things to be aware of when replacing the center piece (metal part):

- The center piece is being turned 180 degrees in the plastic joints to lock.
- This means that at least two of the plastic joints need to be removed from Walkstool to be able to remove the center piece and attach a new one.

We advise you to do the following when replacing the center piece on Walkstool:

- Remove the lower legs completely from Walkstool (when in locked position, push the red spring and pull out the lower legs).
- Remove two plastic joints from the upper legs without damaging the aluminum tubes.
- Remove the center piece and the two plastic joints from the plastic joint that is still attached to Walkstool.
- Attach the new center piece with two new plastic joints – and after that to the third plastic joint on Walkstool (remember that all plastic joints need to be locked to the center piece by turning 180 degrees).
- Use a rubber hammer to attach the two plastic joints on the upper legs. On every stroke, pay extra attention that the plastic joint is in a straight position when attaching it to the upper leg.
- Insert each lower leg into the upper legs by pushing both sides of the red plastic spring.

Best regards,  
Scandinavian Touch AB



*Headoffice*

SCANDINAVIAN TOUCH AB  
BJÖRKALLÉN 17, SE-142 66 TRÅNGSUND, SWEDEN  
PHONE +46 8 676 07 00  
www.walkstool.com







*Production & Administration*





SCANDINAVIAN TOUCH AB  
LINDHAGSGATAN 5C, SE-531 40 LIDKÖPING, SWEDEN  
PHONE +46 510 54 77 99  
E-MAIL info@walkstool.com



# Walkstool®

Comfort models






1	2	3	4	5	6
					
Plastic stud	Seat	Plastic cup	Upper leg	Plastic joint	Center piece




7	8	9	10
			
Lower leg	Red spring	Plastic end	Rubber foot



# Walkstool®

Basic models

1	2	3	4	5	6
					
Plastic stud	Seat	Plastic cup	Upper leg	Plastic joint	Center piece

7	8	9
		
Lower leg	Red spring	Plastic foot

